



Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910

Light	Part no.	Symbol	Colour		Light	Part no.	Symbol	Colour	
Light	9XT 713 630-301		green	001	Interior light, medium	9XT 714 300-031		green	021
Dipped beam	9XT 713 630-311		green	002	Interior light, weak	9XT 713 630-501		green	022
Main beam	9XT 714 300-131		blue	002	Interior light, illumination, bright	9XT 714 300-241		green	023
Additional main beam	9XT 714 300-671		blue	004	Interior light, illumination, weak				024
Fog light	9XT 713 630-351		green	005	Light off			green	025
Work light front	9XT 713 630-421		green	006	Map light	9XT 713 630-511		green	026
Work light rear	9XT 713 630-701 9XT 740 763-491		green red	007	Map light			green	027
Position light	9XT 713 630-331		green	009	Driving compartment lighting	9XT 713 630-491		green	028
Side light	9XT 714 300-651		green	010	Passenger-side lighting			green	029
Position light 1	9XT 714 300-681		green	011	Boot lighting	9XT 713 630-641		green	030
Rear fog light	9XT 713 630-361 9XT 713 630-411		yellow green	012	Main light	9XT 713 630-261		green	031
Indicator	9XT 714 300-141		green	014	Room lamps	9XT 714 300-321		green	032
Warning light	9XT 713 630-391		red	015	Worklighting 1	9XT 713 630-371 9XT 734 713-121		green yellow	033
Warning light	9XT 714 300-691		orange	016	Worklighting 2	9XT 713 630-371			034
Front flasher	9XT 740 763-571		green	017	Table light	9XT 714 300-721		green	035
Cargo area illumination	9XT 740 763-311		yellow	018	Night light	9XT 714 300-701		green	036
Instrument panel	9XT 714 300-661		green	019	Rotating beacon 1	9XT 713 630-281 9XT 713 630-711		green yellow	037
Interior light, bright	9XT 713 630-271		green	020	Rotating beacon 2				038

All symbol cards with part no. are packed in 25s.

Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910



Light	Part no.	Symbol	Colour		Light	Part no.	Symbol	Colour	
Light switch 1				039	UFB				221
Light switch 2				040	Rod-type light				223
Bulb test	9XT 714 300-501		green	226	Rear fog light on/off				229
Light pole	9XT 740 763-601		yellow		Worklighting top				234
Bulb	9XT 740 763-121		red		Fog light off				234
Stairs	9XT 740 763-701		green		Adjustment work light				265
Rotating beacon				205	Wall illumination				325
Light pole				208	Headlights up				334
Tool room				209	Headlights down				335
RKL driver cab				212	Boom light				342
Rotating beacon 3				213					
Signal				214					
Front flasher				215					
Front flasher				216					
Rear flasher				217					
Rear flasher				218					
VWA				219					
RFS				220					

All symbol cards with part no. are packed in 25s.



Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910

Brake system	Part no.	Symbol	Colour		Sight	Part no.	Symbol	Colour	
Parking brake	9XT 714 300-011		red	086	Windscreen wiper	9XT 713 630-101		green	170
Brake malfunction	9XT 714 300-231		red	087	Windscreen wiper/wash	9XT 713 630-121		green	171
Hand brake				088	Windscreen wash	9XT 713 630-131		green	172
Brake lining				089	Wiping intervall switch	9XT 740 763-371		green	173
Oil pressure	9XT 740 763-391			089	Rear windowwiper	9XT 713 630-141		green	174
ASR			yellow	091	Heated rear window	9XT 713 630-231		yellow	175
Disable ASR	9XT 714 300-491		green	332	Heated outside mirror	9XT 713 630-481		green	176
Retarder				227	Windscreen defrosting	9XT 714 300-761		yellow	177
Engine Brake				228	Defroster	9XT 713 630-521		green	179
Retarder 2				272	Heated door window				230
Retarder 1				313	Defroster stage 1				257
ABS				314	Defroster stage 2				258
Brake				316	Windscreen wash				280
Retarder switched off				355	Wiping intervall				281
					Heated window				293
					Heated window				294

3

All symbol cards with part no. are packed in 25s.

Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910



Inside	Part no.	Symbol	Colour		Inside	Part no.	Symbol	Colour	
Lifting roof	9XT 714 300-021		green	138	Auxiliary heating 1	9XT 713 630-211		green	166
Central locking system	9XT 714 300-541		green	149	Heater fan	9XT 713 630-221		green	167
Window lift	9XT 713 630-181		green	150	Seat heating	9XT 714 300-781		green	168
Window lift	9XT 714 300-041		yellow	151	Heating driver's side	9XT 714 300-791		green	169
Window lift	9XT 714 300-341		green	152	Buzzer	9XT 714 300-641		green	
Sun roof			green	153	Auxiliary heating 2	9XT 713 630-601		green	
Air conditioning	9XT 714 300-771		green	154	Arrow, down				211
Fan, fast	9XT 713 630-251		green	155	Description AC				235
Fan, slow	9XT 713 630-531		green	156	Window lift up				236
Fan, fast/slow	9XT 714 300-311		green	157	Window lift down				237
Fan, speed adjustment	9XT 740 763-511		green	158	Window up				249
Fan	9XT 714 300-751		green	159	Window down				250
Fresh air	9XT 713 630-291		green	160	Window dark up				251
Air filter	9XT 740 763-401		yellow	161	Window dark down				252
Roof fan	9XT 713 630-681		green	162	Fan				284
Activate sunshades	9XT 714 300-591		green	163	Sun protection up				285
Heater	9XT 713 630-201		green	164	Sun protection down				286
Heater	9XT 713 630-671		green	165	Heaters slow				287

All symbol cards with part no. are packed in 25s.



Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910

Inside	Part no.	Symbol	Colour		Body	Part no.	Symbol	Colour	
Seat heating on				288	Level adjustment	9XT 714 300-471		yellow	128
Heating stage 1				289	Level 1				129
Heating stage 2				290	Height adjustment	9XT 714 300-071		yellow	130
Fan slow				291	Lower	9XT 713 630-621		yellow	131
Fan fast				292	Raise	9XT 713 630-631		green	132
Container heating				295	Raise			yellow	135
Front ventilation damper				296	Raise/lower	9XT 734 713-521		yellow	136
Recirculation mode				297	All raise/ lower			yellow	137
Roof ventilation driver seat				298	Lifting table head down/up	9XT 714 300-251		green	139
Roof deaeration driver seat				299	Operating hydraulic system				140
Jalousie up				307	Trailing axle			green	141
Jalousie down				308	Full floating axle	9XT 713 630-761		yellow	142
Rollo up / down				359	Lift axle				143
					Deaeration 3rd axle axle raise	9XT 714 300-431		green	144
					Dumping	9XT 734 713-281		orange	145
					Cylinder down			yellow	146
					Cylinder down rapid			yellow	147
					Ground pressure regulator	9XT 740 763-501		green	148

3

All symbol cards with part no. are packed in 25s.

Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910



Body	Part no.	Symbol	Colour		Body	Part no.	Symbol	Colour	
Lifting table on/off	9XT 714 300-261		green		Close 2nd door				323
Lock Telescopic arm 1	9XT 714 300-161		green		Open 3rd door				328
Support right	9XT 713 630-731		green		Close 3rd door				329
Support left	9XT 713 630-741		green		Open cabin				338
Operating hydraulic system	9XT 734 713-551		red		Close cabin				339
Tipper, loading-area repositioning (turned 180°)	9XT 740 763-531 9XT 740 763-541		green red		Driving position				354
Driving side door									225
Cab lock									240
Tilt cabin									274
Door PRG									276
Lower bus									278
Door right									279
Open trunk									317
Lock trunk									318
Open ventilating hatch									319
Ventilating hatch closed									320
Close 1st door									321
Open 2nd door									322

All symbol cards with part no. are packed in 25s.



Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910

Drive	Part no.	Symbol	Colour		Drive	Part no.	Symbol	Colour	
Lubrication	9XT 714 300-181		red	092	All-wheel drive	9XT 734 713-771		green	109
Engine start	9XT 714 300-381		green	093	Power take-off	9XT 734 713-231		green	110
Preheating	9XT 714 300-391		yellow	094	Differential lock	9XT 714 300-111		green	111
Preheating fuel	9XT 714 300-481		green	095	Differential lock			green	112
Engine stop	9XT 714 300-401		red	096	Differential lock	9XT 740 763-331		red	113
Motor malfunction	9XT 734 713-431		yellow	097	Differential lock	9XT 740 763-381		red	114
Throttle valve				098	Automatic idle	9XT 713 630-751		red	116
Increased rpm	9XT 714 300-421		orange	099	Fuel	9XT 734 713-511		yellow	117
Battery	9XT 714 300-201		yellow	100	Change-over tanks	9XT 714 300-051		green	118
Auxiliary battery	9XT 714 300-331		green	101	Turbine	9XT 740 763-341		red	119
Breaker 1	9XT 740 763-231		green	102	Speed of PTO s haft, front	9XT 744 039-002		yellow	120
Breaker 2				102	All-wheel drive	9XT 734 713-411		yellow	121
Temperature	9XT 714 300-191		red	103	Transmission oil pressure	9XT 734 713-591		red	122
Pre-heater	9XT 713 630-451		yellow	104	Transmission, oil temperature	9XT 734 713-611		red	123
STOP	9XT 734 713-211		green	105	Hydraulic oil filter	9XT 734 713-371		red	124
On/off			green	106	Torque converter oil filter			red	125
Fast	9XT 713 630-401		green	107	Oil pressure/ temperature	9XT 744 039-052		red	126
Slow	9XT 713 630-691		yellow	108	Interruption in power train			green	127

3

All symbol cards with part no. are packed in 25s.

Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910



Drive	Part no.	Symbol	Colour		Drive	Part no.	Symbol	Colour	
Start	9XT 734 713-151		green		Rear-wheel drive off				300
Vibrating device	9XT 734 713-341		yellow		All-wheel drive off				301
Steering aid 1	9XT 734 713-421		red		ECO				304
Steering aid 2	9XT 734 713-351		red		Engine				315
Fremo Motore/Retarder	9XT 744 039-082		green		Min level hydraulic oil				326
Undervoltage				206	Air circulation				327
Right-hand drive				238	Decrease speed				336
Right-hand drive				238 R	Increase speed				337
Left-hand drive				239	Engine increasing				346
Left-hand drive				239 R	Engine STOP				347
Start				241	Engine check				348
Engine				242	Engine cooling				351
Additional axle				246	Battery Main				353
Separate steering (can be turned through 180°)				247					
Air supply system left				255					
Air supply system right				256					
Battery low				261					
Battery bypass				262					

All symbol cards with part no. are packed in 25s.



Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910

Auxiliary symbol cards	Part no.	Symbol	Colour		Auxiliary symbol cards	Part no.	Symbol	Colour	
Without symbol	9XT 713 630-001 9XT 713 630-011 9XT 713 630-021 9XT 713 630-031 9XT 734 713-131 9XT 734 713-621 9XT 740 763-291		green black red yellow clear blue orange		Bell				056
Without laser symbol				000	Door opener	9XT 714 300-631		green	057
Overload warning device	9XT 713 630-381		red	041	Front door	9XT 713 630-551		green	058
Compressed air horn Hom	9XT 713 630-461 9XT 734 713-601		green black	042	Rear door	9XT 713 630-561		green	059
Hom	9XT 734 713-601			043	Door plate	9XT 740 763-251		red	060
Hom test button WA 3	9XT 714 300-291		green	044	Arrow, up	9XT 740 763-461		yellow	061
Signal-switch-over	9XT 714 300-301		green	045	Arrow, left	9XT 740 763-451		yellow	062
Reverse signal	9XT 734 713-241		green	046	Arrow, right	9XT 740 763-471		yellow	063
City/ country signal	9XT 740 763-581		green	047	Tail gate	9XT 740 763-591		green	064
Km/h			green	048	Cutting tool, reversing	9XT 740 763-481		green	065
Speed limit			yellow	049	Cutting tool, locked			red	066
WC	9XT 713 630-591		green	050	Socket	9XT 714 300-611		green	067
TV	9XT 714 300-551		green	051	Water on/off	9XT 744 039-012		orange	068
Camera	9XT 714 300-561		green	052	Plate broom (turned left)	9XT 734 713-251		orange	069
Radio/Music	9XT 714 300-571		green	053	Plate broom (turned right)				070
Refrigerator	9XT 714 300-101		green	054	Plate broom up	9XT 734 713-271		orange	071
Bell			green	055	Double plate broom			orange	072
					Plate broom			orange	073

All symbol cards with part no. are packed in 25s.

Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910



Auxiliary symbol cards	Part no.	Symbol	Colour		Auxiliary symbol cards	Part no.	Symbol	Colour	
Plate broom spray water	9XT 740 763-621		green	074	Rear warning unit				210
Brush right on/off			orange	075	Rear warning unit				211
Brush raise/lower	9XT 744 039-042		orange	076	Working tool				222
Brush side	9XT 740 763-711		green	077	Water pump				224
Spray water	9XT 740 763-631		green	078	Driving side door				225
Hasp	9XT 740 763-641		green	079	Retarder				227
Broom up/down	9XT 740 763-651		green	080	Engine Brake				228
Dumping	9XT 740 763-611		white	081	ISO 2W	9XT 714 300-731		green	
Fast tipping	9XT 740 763-681		white	082	Hostess-call	9XT 714 300-581		green	
Auxiliary unit open	9XT 740 763-661		red	083	Off-road gear	9XT 734 713-401		green	
Float position				084	Fuel leak cut-off	9XT 714 300-001		orange	
Wheel chair				085	Exhaust	9XT 714 300-281		green	
WAIL Signal				180	Mann with stik	9XT 714 300-621		orange	
YELP-Signal				181	Signal light wheelchair	9XT 740 763-001		red	
HILO-Signal				181	Caution	9XT 740 763-011		red	
Step				183	Unsuitable for wheelchair	9XT 740 763-081		red	
Undervoltage				206	Suitable for wheelchair	9XT 740 763-101		green	
Radio				207	Wheelchair	9XT 744 039-212		blue	

All symbol cards with part no. are packed in 25s.



Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910

Auxiliary symbol cards	Part no.	Symbol	Colour		Auxiliary symbol cards	Part no.	Symbol	Colour	
Fire alarm	9XT 744 039-092		red		Socket off				263
ZIG ZAG	9XT 744 039-062		red		Hook				264
Proportional function	9XT 744 039-132		green		Slewing gear				266
High-pressure cleaner			green		Hook 2nd level				267
Funnel drain			green		Throttle body				268
Hose	9XT 744 039-192		green		Hook 1st level				269
Request next stop				194	Boom up				270
Lower				195	Raise / Lower boom				271
Radio				207	Extend / Retract boom				273
Main switch, radio				231	Raise / Lower boom cap				275
Monitor control				232	INFO				277
Pump				243	Return				282
Cap lock				244	OK				283
Autom. Cap lock				245	Hydraulic gear pump off				302
Intercom				248	Hydraulic gear pump on				303
Malfunction vehicle electronics				253	RAG				305
Water level diesel engine				254	Slew ring blocked				306
Hom off				259	BORD SONDOR				309

3

All symbol cards with part no. are packed in 25s.

Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910







Auxiliary symbol cards	Part no.	Symbol	Colour		Auxiliary symbol cards	Part no.	Symbol	Colour	
SEL II				310	Driver light				358
N				311	Driver microphone				360
Coffee				312	Hostess call-boiler				361
Emergency				324	Panorama camera				362
INFO				330	Universal camera				363
Heating pump				331	Park distance control				364
Bridge hoist end switch				333	Toilet dump				365
Bridge boom				340	Refrigerator				366
Setup RCL				341	Outlet Fan				367
CASSA				343	Fresh air				368
Hostess call				344	Heater				369
LIM				345	Request for stop-off				370
Locking cargo-body				349	Stop				371
Alternative steering wheel				350	Ticket machine				372
Hydromech. transmission				352	Snow chains				373
Lane departure warning				356	Loudspeaker				374
Central locking				357	Handicapped access				375

All symbol cards with part no. are packed in 25s.



Switches

Symbol cards for 354 100 / 007 832 / 008 948 / 004 570 / 008 910

Auxiliary symbol cards	Part no.	Symbol	Colour	
(Media on demand)				376
Light sleeping compartment				377
Heating sleeping compartment				378

All symbol cards with part no. are packed in 25s.